



Front Surround System

ESB-1090

EN Quick Start Guide

Contents

Accessories	3
Remote control	4
Installation	5
Connections	5

About this Quick Start Guide

- This document explains connection of this unit to a computer, AV device, or TV that supports Audio Return Channel (ARC). See the Owner's Manual for instructions on operating the unit. The Owner's Manual is available from the following websites:
 - U.S.A. and Canada
<https://uc.yamaha.com/support/>
 - Other countries
<https://download.yamaha.com/>
- The illustrations in this document are for instructional purposes only. For any information on devices other than this unit, refer to each device's respective documentation.
- The terms HDMI, the HDMI Logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

Accessories

Make sure you have received all of the following accessories.



The unit (ESB-1090)



Remote control

A CR2025 Lithium battery has already been inserted into the remote control.




Power cord




Optical digital audio cable

Use when connecting the unit to a TV that does not support ARC.



Spacers (x 2/sheet)

Use when mounting the unit on a wall.



Mounting template

Use when mounting the unit on a wall.



Quick Start Guide (this booklet)



Safety Brochure


■ **NOTE**

HDMI cables are not supplied with the unit. Use the HDMI cables purchased separately.

Remote control


Preparing the remote control

Remove the battery insulating strip before attempting to use the remote control.



Operating range of the remote control


Operate the remote control within the range as shown below.



Installation


Installing the unit on a TV stand

Install the unit as shown below.



Connections


Overview




1 Connecting a computer or AV device

If only a TV will be connected, skip this step and proceed to step

2.




2 Connecting an Audio Return Channel (ARC) compatible TV



3 Connecting the power cord

After all connections are complete, connect the supplied power cord to the power connector on the unit and then plug the power cord into an AC wall outlet.



When the power cord is plugged into an outlet, the unit automatically turns on.

■ IMPORTANT

- This unit is set to Conference mode (mode for using the unit as a speaker for remote conferencing) by default. To prevent accidental operation during a remote conference, the unit's ⏻ (power) button cannot be operated in Conference mode (the remote control can be used to turn the unit on/off).
- See the Owner's Manual for instructions on operating the unit, including operating and canceling Conference mode. The Owner's Manual is available from the following websites:

U.S.A. and Canada

<https://uc.yamaha.com/support/>

Other countries

<https://download.yamaha.com/>

YAMAHA CORPORATION

10-1 Nakazawa-cho, Naka-ku, Hamamatsu, 430-8650 Japan

Yamaha Global Site

U.S.A. and Canada

<https://uc.yamaha.com/>

Other countries

<https://www.yamaha.com/>

Yamaha Downloads

U.S.A. and Canada

<https://uc.yamaha.com/support/>

Other countries

<https://download.yamaha.com/>

Manual Development Group

© 2021 Yamaha Corporation

Published 04/2021 KSOD-A0

VQX1A2282Z

B